OPUS CAMPER

OPUS

OPÚŜ

OWNER'S MANUAL

FF-ROA

OPÚÈ

Model OP15

0P15V22020

:0PÚÈ

R

A MESSAGE FROM <



Hello and Welcome!

We're so pleased that you have chosen an OPUS Camper Trailer and we welcome you to the adventure lifestyle. Our goal is to help every customer push boundaries and explore further, to find and to foster that love for the great outdoors, and with the help of their Off-Road trailer as a base camp we hope to help our customers find their inner adventurer.

We are committed to providing the highest level of customer service and so we've put together this user manual to help guide you through the process of learning about your new OPUS trailer. We strongly suggest that you review this manual in its entirety before using your new Opus Camper. Your dealership should be able to answer any questions you have and we are very happy to assist with any further questions that arise. Getting to know your new camper well and following the guidelines, instructions and warnings laid out in this manual will help to ensure that you get the most out of your camper and with considerate treatment and care it will be your companion for your camping adventures for years to come. We recommend that you keep this Owner's Manual with your camper as a reference guide for when you are out on your adventures. If you need a digital copy of this manual please contact us at OPUS Camper USA and we would be happy to provide you with one.

Here at OPUS we demand a high standard of build in our trailers; to ensure the highest quality our team follow a strict build and inspection process before delivery. Your dealership will also run their own inspection on the camper before it reaches you. We encourage you to take the time with your dealer when you collect your trailer to familiarize yourself with the camper and understand the tests that they have run to ensure that everything is working as it should.

If you suspect your OPUS Camper is not working correctly, please contact your dealer to arrange an appointment. If you are travelling and experience a problem, please first contact your dealership before any repairs are carried out by a local independent service department to ensure that you will still be covered under warranty. Retain all invoices and documentation to allow for proper reimbursement through your dealer. For appliances, please refer to the appliance manual for support and warranty assistance.

The OP15 trailer is designed for recreational use only. We would encourage you to familiarize yourself with the warranty for your trailer to ensure that your use falls in line with the intended usage covered under warranty. Usage outside of these terms could reduce or void your warranty. You will find the OPUS warranty information in the back of this user manual. Please be sure to follow up with your dealership to make sure they have completed and returned the required warranty registration form to activate your warranty.

Please note that there may be differences in the products or design shown or described in this manual from your camper. This manual was correct at the time of publication however we promote an on-going improvement process within our builds and we reserve the right to change the construction or design at any time without the obligation to make these changes on previous manufactured trailers. If significant changes are made to the design or build of our models we will take the appropriate steps to update this manual accordingly for the benefit of our customers. Please contact the OPUS Camper USA team for a digital copy for our most up to date user manual.

Should you have any questions about your OP15 trailer, no matter how small we are here to help. You can reach us at info@opuscamper.us or call us on 925.215.7215.

We hope you enjoy your OPUS Camper and we wish you many happy memories

Sincerely,

The OPUS Camper Team

CONTENTS

My OPUS	4
Vehicle Identification Number (VIN)	5
Specifications	6
Dimensions	8
OPUS Quick Set up Guide	9
Hitching & Towing electrics	10
OPUS brake Set up	11
OPUS Control Panel	12
Setting up your OP15	13
120 Volt & 12 Volt Power	16
Water System	18
Propane System	20
Truma Water/ Heating System	22
Setting up your OP15 awning	23
Rooftop A/C	23
OP15 Kitchen	24
Bathroom	26
TV & Stereo	27
Windows & Door	28
Packing Down your OPUS	30
Tips & Troubleshooting	31
Care & Maintenance	31
Warranty	38

MY OPUS CAMPER

(This information can be found on the tire sticker on your OP4 door)

VEHICLE IDENTIFICATION NUMBER (VIN)

About your Vehicle Identification Number

Every OPUS has a Vehicle Identification Number (VIN). The VIN Plate can be found on the exterior of your OP15, on the chassis behind the tongue jack wheel. We recommend making a note of your VIN on the opposite page. This will be required by insurance companies



SPECIFICATIONS

Build

Bodywork	Baked enamel finish
Material	Di-bond Aluminum composite panel exterior with an Aluminum sub-structure
Dimensions (Travel Mode)	257" (L) x 106" (H) x 83" (W)
Dimensions (SetUp Mode)	280" (L) x 120" (H) x 154 (W with kitchen fully extended)
Ground Clearance	14"
Chassis	Fully galvanized & welded chassis
Drawbar	Fully galvanized & welded drawbar
Bed Mattress Size (Main Bed)	72" (L) x 70" (W) x 8.5" (H)
Bed Mattress Size (Bunks)	Bottom: 80" (L) x 42" (W) x 3" (H) Top: 80" (L) x 33" (W*) x 2" (H)
Dry Weight	4960lbs
Tongue Weight	397lbs
GVWR	6600lbs
Cargo Capacity	1640lbs

Features

Hitch	Lock'n'roll articulating Off-Road hitch
Suspension	Independent Trailing Arm Coil Spring Suspension
Shock Absorbers	Gas Shock Absorbers
Kitchen	Exterior Slide out Stainless Steel Kitchen with 4 burner gas stove & sink with electric tap, dish rack and cutlery drawer.
Kitchen Prep Deck	Lockable Fold-down Kitchen prep deck
Refrigerator	Dometic CFX75
Stabilizers	Drop Down Adjustable Heavy Duty Stabilizer legs
Tongue Jack Wheel	ARK 750 Dual Tongue Jack
Steps	Power step
Stone Guard	Anti-chip protected
Wheels	265/75R/16 Mud Tires (including 2 x spares) and Alloy Wheels
Brake System	12v Electric Drum Brakes with additional E-brake to assist with un-hitching and trailer brake-away system.
Pop-Top Roof	Aluminum frame with top aluminum sheet and Fiberglass interior wall
Sun Awning	8' Girard Retractable Awning

Interior

_		<u></u>
Seating/Dining	Leatherette Seating with adjustable pivot position table	
Furniture	Premium Bamboo Interior Cabinetry and wardrobe	1
Bathroom	Ensuite with premium shower, sink and chemical toilet	
Heating	Truma Combi Heater and Hot Water System (runs off propane & 12v)	
A/C	Dometic 13,500 BTU 120v A/C	

Electrical

Batteries	3 x 100 ah 12 volt AGM batteries
Solar	3 x 100 watt solar panels with Renergy 30 amp solar charge controller
TV	12v capable TV with exterior mounting bracket and Antenna
Lights	Interior & Exterior 12v powered LED Lights
Shore Power	30 amp shore power connection & cable
Stereo	12v Stereo with interior & exterior speakers, Bluetooth & direct connection, CD and Radio

Water

Potable Water Capacity	63 gallons (spread across 2 tanks)
Grey Water Capacity	17 gallons
Black Water Capacity	10 gallons
Water tank guard	Checker plate
Water system	1 x 12v electric pump
Hot Water	Truma Combi Heater and Hot Water System (runs off propane & 12v) provides hot water to the outdoor kitchen sink and the indoor bathroom sink and shower



Set-Up Mode



Travel Mode



OP15 QUICK SET-UP GUIDE

We strongly recommend that you review the OPUS OP15 User Manual thoroughly before setting up your OP15 for the first time. This quick set-up guide is intended as a supplementary refence guide with a summary overview of the steps involved in setting up your OP15 Caravan

STEP ONE

Apply e-brake, lower the tongue jack & lower the corner steadies to level your trailer. Fold down the spare tires. Disconnect the roof latches.

STEP TWO

Open rear panel securing locks & lift the back panel to the roof position. Pull & rotate side panel securing spring bolt. Open the left & Right Side panels fully to meet the roof grooves.

STEP THREE

Unlock the rear bed fold-down section and carefully fold down the bed section. Lift the rear end wall panel in place and secure with pins & latch clamps.



STEP FOUR

Slide out the kitchen and connect the water and gas quick-connects. Connect your sink drain hose and set up your grey water collection



STEP FIVE

Open & latch the door. Turn on trailer power and lights. Fold down the power steps. Inside, fold down the main bed mattress



STEP SIX

Pull out all four securing pins for BOTH the front & rear lifting mechanisms before lifting. Lift the interior roof-lift bars front end first then rear end. Slide securing pins in place.



HITCHING, TOWING & BREAKING

About your Hitch

The OP15 comes as standard with a Lock'n'Roll articulating hitch. The hitch allows for pivoting on 3 axis and provides an overall smoother towing experience. Ensure the locking pin is fully inserted and secured in place before towing. When hitching the OPUS[®] to your towing vehicle you must ensure that someone is close to the handbrake in order to maintain control of the trailer, particularly when unhitching on uneven ground or a slope. The Lock'n'roll hitch is a two-part hitch with a vehicle-side and a driverside part. The vehicle side fits in a 2" hitch receiver and should be locked in place with an appropriate hitch receiver lock. The trailer side is already installed on hour OP15. To connect the two parts, the trailer side pin arms should be placed in the receiving section on the vehicle side part. The hook arms then fit over the trailer-side pin arms and a securing pin is fitted through the holes in the hook arms and the hole in the main receiving section on the vehicle side part. This will hold the trailer side pin arms in place. Use a locking pin on the securing pin to fully lock the coupling in place.



Correct Hitch Coupling position for travel. Hook arms fit over trailer-side pin arms. NOTE securing pin through holes in hook arms and locking pin to hold it in place



HITCHING, TOWING & BREAKING





About your Electrical Plug

7 PIN The OPUS[®] is fitted with a 7-pin flat plug that connects all the exterior trailer ltrailer running/break/turn lights and the electric brakes to the towing vehicle. You will require a 7-pin connection on your tow-vehicle as well as an in-car electric break controller installed in your tow vehicle to operate them.

Installing your Safety Chains

The OPUS[®] is fitted with 2 safety chains on the tongue. One end of each chain is fitted to the OPUS[®] chassis and the other end has an attachment clip which should be attached securely to your tow vehicle bumper or receiver. Ensure the clips on the hooks are in place to fully secure the hooks. Do not attach the hooks to the hitch itself. Ensure that you have enough slack in the chains to turn your vehicle adequately. Should you require less slack, the chains can be twisted or crossed below the tongue before connecting to your vehicle to ensure the chains do not drag on the ground.



About your Brakes

The OPUS[®] is fitted with electric trailer brakes. You need an electric brake controller fitted to your car in order to tow the OPUS[®] and operate the electric brakes safely. Failure to tow with a brake controller in your vehicle is both dangerous and illegal. You can tell if your brakes are working properly by connecting the 7-pin plug, starting the engine of the tow vehicle and then getting someone to listen to the brake hub whilst another person applies the brakes in the tow vehicle. If they are working correctly you will here a low humming sound as the brakes are applied. As part of the annual service check you should have completed by an accredited industry service agent, the brakes will be checked and maintained.

Towing

The driver of the tow vehicle must ensure that their Driving License is valid for towing the OPUS[®] Camper. It is highly recommended, particularly if you are not experienced in towing that you adhere to any applicable laws for the state in which you are driving. Many guides are available from leading associations and should be studied before you embark.

OP15 CONTROL PANEL

Control Panel Features

- 1. Power ON/OFF button
- 2. Battery level indicator
- 3. Volt Meter
- 4. Amp Meter
- 5. Front Water Tank Level Gauge
- 6. Rear Water Tank Level Gauge
- 7. Black Water Tank Level Gauge
- 8. Grey Water Tank Level Gauge
- 9. Fridge outlet power button
- 10. 12 volt socket power button
- 11. Lights power button
- 12. Water Pump power button

The Volt Meter: Measures the current battery voltage output. Most appliances will require at least 12.2v from the batteries otherwise they will not work.

Amp Meter: This shows how many Amps you are currently using. The OPUS[®] has 3 x 100ah AGM batteries. This gives you 150 usable amps for off-site power.

Battery Indicator: This shows the total capacity remaining in your batteries. If you are showing 50% on your battery meter then your batteries will not put out the 12.2v required for most accessories to operate. Ensuring you keep a close eye on all 3 gauges will ensure you are fully informed on the current performance of your 12v battery powered electrical system.

*Each switch on the control panel (power, fridge, sockets, lights and pump) has its own breaker, located directly above the switch.

Understanding the Voltage Meter

The upper number shows what Voltage (power level) the batteries are currently reading. It is the strength of the current flowing from the batteries.

If this number were to drop beneath 12.0v with no load (i.e. no accessories running on the OPUS[®]) then it is highly likely all the appliances inside your camper would stop working as the batteries are not able to put out enough voltage to keep these appliances running.

Do not take a reading when an appliance, such as a fridge, is running. It will give a false reading. Voltage may appear below 12.0 if the batteries are under load (fridge is actively running).

The lower number shows the quantity of energy you are currently utilizing from the batteries. If you imagine a water tank holding 100gallons and you drain 4 gallons an hour (gallons would represent amps), then you can tell how quickly under current usage conditions your batteries will be fully drained. Remember your appliances all cycle at different rates so this number becomes very important for estimating battery life.





SETTING UP YOUR OP15



STEP 1 - Once you have positioned your OPUS[®] in the desired location, engage the e-brake. Try to choose a site that is as level as possible and where the ground is not too soft.

STEP 2 - You can now un-hitch from your tow vehicle if you choose. The lock'n'roll two part hitch can be disconnected by removing the locking pin and unhooking the two hook plates (see page 10 for more information on your hitch)

STEP 3 - Raise or lower the tongue jack wheel to level your OPUS® Horizontally.

STEP 4 - To drop down the corner steadies, pull the blue handle outwards until the leg drops down to a 90 degree angle from the trailer. Using the included corner steady winder (or cordless drill/driver with a 3/4" Hex socket attachment) wind down each corner steady leg until it touches the ground. Depending on the terrain, you may need to adjust each corner to level the OPUS[®] width ways.

It may help to lift the weight of the leg when pulling out the blue handle. NEVER lift the OPUS completely off the ground using just the corner steadies.

STEP 5 - Disconnect the four roof securing latches; Use your thumb to push in the release pin (see 5b & 5c below) then lift the handle to release the latch from the hook completely.



STEP 6 - At the back of the OP15 un-screw the black spare tire securing bolts until they can be removed from the hole completely. **STEP 7** - Next, disconnect the spare tire securing latches using the red lever handle. Fold the handles and triangle pin downwards so they are out of the way of the rear panel. Carefully fold down the spare tire bracket; the arm is gas-strut assisted to help with the weight. Fold the bracket down as far as it will go.



SETTING UP YOUR OP15 cont.

STEP 8 - Use the push-buttons to open the rear panel securing locks. Lift the back panel upwards to the roof position.

WARNING! Please note that this panel will not yet remain in this position without completing the next step.

STEP 9 - Using one hand or a helper to hold the roof panel up, pull and rotate the spring bolt that secures the side panel until it is in the vertical position. This will allow the side panels to swing outwards.



STEP 10 - Open the left side panel fully through 90 degrees, ensuring the panel meets the top left corner groove of the roof panel to complete the set-up and achieve a full seal. Repeat with the right ride panel.

STEP 11 - Holding the bed panel securely, release the two rear bed panel securing latches and fold down the bed panel.

WARNING! Please ensure you or a helper are holding the fold down bed panel before releasing the latches as this panel can shift if you are on any incline or the camper is not completely level. Failure to support the panel fully at this point could result in serious injury or damage to the trailer.









STEP 12 - Carefully lower the rear bed panel into the horizontal position.

WARNING! This panel is heavy especially considering the angle and reach required to hold it. We recommend two people complete this stage of the set up together for the first several uses until you are familiar with its weight and movement and confident that you can complete the set up individually.

STEP 13 - Use the handle to lift the rear end wall panel in place. Slide the two locking pins in place and then secure with the latch clamps.



SETTING UP YOUR OP15 cont.











14h

STEP 14 - Open the two push-button latches and fold down the kitchen door. Unhook the two locking spring-bolts and slide your kitchen out. Quick-connect your water and gas at the kitchen connection points and the quick connects on the side of the OP15. Please see the sections on the **Gas System, Water system** and the **Kitchen** for more information on setting up the kitchen.

STEP 15 - Route your sink drainage hose out of the bottom of the kitchen and into your designated grey water carrier.

STEP 16 - Open and latch your OP15 entry door. Turn on the power and lights. Press the circular button on the left of the entry way to deploy electric step.

STEP 17 - Pull out the securing pins for the front and rear lifting mechanisms.

STEP 18 - Use the interior roof lift bars at the front and rear of the OP15 to push the roof up into place. Slide the securing pins for the roof lifting mechanism into place to secure the roof.

STEP 19 - Fold out the main bed mattress. You will find two additional white cushions covered with the same fabric as the mattress and two additional blue leatherette covered cushions. Place the white cushions on either side of the mattress and the two blue cushions between those cushions at the outer wall to help keep your mattress in place.





120 VOLT & 12 VOLT POWER

120 Volt Shore Power Connection



120v Shore Power Hookup



120v Panel Board

Safe operating procedures

The OP15 comes fitted with a 120 volt power system. This 120 Volt power system complies with NFPA and NEC regulations. The hookup for the 120v is located outside on the driver-side of the OP15. The main circuit breaker panel is located inside the OP15 in the footwell under the master bed. Always ensure you have a clear access to the circuit breaker panel and that it is not blocked at any time. There are 2 internal dual 3-pin 120v outlets with USB sockets and one exterior dual 120v outlet.

The exterior shore power hookup is located on the driver's side at the front of the OP15 and your OP15 comes supplied with a 30ah shore power cable and pigtail connection for both campsite and home outlet connection. Take care to ensure proper maintenance of the power cord and pigtail accessory items. Always use a Listed and approved 20ah cable and adapter and a grounded power source. Never use an extension cord. **DANGER!** Due to potential danger in failing to heed this warning, the recreational vehicle manufacturer cannot be held responsible should damage, injury or death result from failure to connect the power cord to a properly grounded power source.

Invertor information

Your OP15 has a 12v to 120v changeover switch and invertor installed located in a compartment under the master bed, accessed by lifting the mattress and removable panel. If

you are not connected to a 30amp shore power connection the invertor will AUTOMATICALLY begin converting 12v current from your batteries to 120v to supply any connected appliances connected to the 120v outlets. To reserve your 12v battery power we recommend unplugging all 120v appliances if you are not connected to the 30amp shore power hook up. These power hungry appliances will deplete your batteries very quickly (even with the solar-assisted charging) so we recommend using this functionality sparingly. Please pay very close attention to your amp meter if you are running a 120v appliance via the invertor; try plugging each appliance in separately to check its amperage draw to help you better understand and manage your power supply. Please note that the A/C system requires 120v shore power to run. You cannot run the A/C system off of your batteries as it **WILL DRAIN YOUR BATTERIES** in a very short period of time. For more information on using you're A/C system please see the A/C section of this manual. There are no other 120v appliances or systems built into the OP15 as standard.



12 Volt Battery Power

The OP15 has three 100ah deep cycle marine batteries installed as well as a fully automatic battery charge controller. You will need to charge your batteries for at least 24hrs prior to each trip using a 120volt shore power connection to ensure that they are fully charged. The main control panel has a battery volt-meter that will provide an indication of the charge level of your batteries. A fully charged battery bank will be indicated by a full battery symbol and the voltmeter reading around 13.7volts . If you are at a campsite with shore power then we recommend connecting for the duration of your stay to keep your batteries fully charged. If you are camping off-site without 120volt power then the length of time that your batteries will last will depend on

how much 12volt energy you use, how much solar power you are generating to recharge the batteries (see below "Solar Power" Section), the 'health' or condition of your batteries and in some cases the ambient temperature. Your control panel will show you how much power you are using and how much remaining power is in your batteries to help you manage your power consumption.



120 VOLT & 12 VOLT POWER cont.

12 Volt Battery Power cont.

On the control panel you will find the main 12v ON/OFF switch. There are separate switches for the following 12volt operated appliances and systems in the OP15: Fridge, Sockets, Lights, Water Pump.

The OP15 has two 12v outlets for the interior TV hookup, two for the exterior TV hookup and one exterior 12v socket by the kitchen. The internal and external lights for your OP15 are all 12v LED. They can all be switched on or off independently either on the light itself or on via a switch in the OP15.





- The battery indicator on your control panel will show how much energy is left in your battery bank. It is important to note that it does NOT explicitly show how much useable power is left in your batteries.
- You have a 300 amp battery system. AGM batteries are able to reliably put out over 12.0v of power for 50% of their capacity. Most 12v appliances will require a 12volt output from the batteries to work. This means you **150 usable amp hours** from a fully charge set of batteries. The indicator on your control panel will show you how much total energy you have in your entire battery bank. This means that when your indicator shows 50% you have used all of the usable power within your battery bank. If you continue to drain power from your batteries beyond this point can and will most likely cause damage to your battery bank.
- AGM battery lifespans are longer when they remain at full charge. Frequently discharging your batteries and leaving them empty will accelerate the degradation process of your batteries and reduce their lifespan. The NOCO Genius charger installed in your OP15 will control the amount of charge delivered to your batteries so that they do not over charge, therefore you can leave your OP15 plugged in at all times when at home.
- If you are not keeping your OP15 plugged in whilst at home we recommend that you disconnect your batteries to maintain good battery health. Please see the *care and maintenance section for more information on this topic.
- The CO/LP alarm is wired directly to the batteries. This means that turning the power to the OP15 off on the control panel will **NOT** shut power off to the CO Alarm. Please follow the winterization process for battery care to ensure you are fully disconnecting the batteries during long periods of storage.
- Always set your fridge to 'LO' before heading out on your trip. This will use less power from your battery and allow you longer off-site camping.



Solar Power

There are three 100 watt solar panels mounted to the roof of the OP15 with a 30amp solar charge controller installed. During the day with adequate sunlight, the solar panels will automatically trickle charge your batteries. We recommend reading the user manual for your solar panels & charge controller in full to understand the capabilities and settings for the solar panels and charge controller.

<section-header><complex-block><complex-block>

Potable Water System

The OP15 is fitted with two 31 gallon fresh water tanks mounted under the OP15 towards the middle and rear of the trailer. The water tanks have two fill points located on the driver-side of the OP15 and identified by a blue water faucet icon.



WARNING: Only potable water from a reliable source should be used in these tanks. Do NOT store water in the tanks for more than two weeks. Please ensure you sanitize, flush and drain the water tanks before using and a minimum of every 6 months thereafter or if you suspect there's an issue with the quality of your water. Do NOT use bleach to sanitize the tanks as they are stainless steel and it will cause corrosion. Please see the OPUS Care & Maintenance section of this manual for more information on sanitizing your water system. Failure to maintain your tank can result in death or serious injury.

Your water system is connected to the 12v water pump which can be switched on via the main control panel. Your two potable water tanks may be used to supply water to the bathroom including the shower and sink as well as the kitchen sink. The potable water tanks also supply water to the Truma hot water system AND the flushable toilet (see each section on the following page for more information on these systems). The water pumps are pressure operated, so once the main power switch is turned on at the control panel the pump will prime the system and as soon as you turn the tap on the water will flow. Once the tap is closed, the pump will turn off until the tap is turned back on. Please turn off your pump at the main control panel



when the water system is not in use as they will continue to use battery power when they are turned on but not in use. Do not run your water pump when the tanks are empty as this could cause the damage to the water pump and circuit.

You can use the water gauges on the main control panel to check the water levels in each tank. The tanks are gravity filled and included with your OP15 is a potable water fill hose which should also be sanitized regularly. It is important to monitor the water levels in your tanks. When your water tanks or empty please turn off your water pump. Running your pumps without water in the tank will cause your water pumps to burn out. Please see the Troubleshooting section for tips if you are not able to draw from your potable water tanks

You can set your water pump to draw from EITHER the front OR the rear tank OR from both tanks. To do this, locate the selector lever located under your OP15, behind the driver-side wheel. You will see a blue lever at a junction of three water pipes. To select the FRONT tank, move the lever through 90° towards the F marking in the direction of the rear of the trailer. To select the REAR tank, move the lever towards the R marking in the direction of the front of the trailer. To select BOTH tanks move the lever to the center of the markings, so that the red arrows line up with the three water pipes. **Please note if either of your water tanks is EMPTY please move the selector to the other tank and do not leave it on BOTH tanks.**



WATER SYSTEM CONT.

Draining your potable water tanks

Located on each potable water tank you will find a draining valve at the lowest point of the tank. When packing away the OP15 complete the following process to drain the system of any excess water.

- A. Switch off the pump on the main control panel
- B. Open the faucet & allow the excess water in the pipe to drain
- C. Close the faucet once all of the water has drained.
- D. Disconnect either side of the quick connect

E. Ensure the sink is emptied and that the waste water drain hose is empty before folding it back into the kitchen. Please refer to the steps in the care and maintenance section of this user manual for more information on draining and preparing your tanks for storage.



Gray Water System

The OP15 gray water tank has a capacity of 17 gallons and is the front most tank on the underside of your trailer. It collects the gray water from your shower and bathroom sink. Please note that your kitchen sink does not drain into the gray water tank. Please visit the Kitchen section of this manual for more information on the kitchen sink drain. You should continually monitor the fill level of your gray tank using the gauge on the main control panel during use. We recommend emptying your gray tank when it is around 3/4 full. You will find the gray water drain outlet on the gray water tank. Please remember to dispose of gray water safely at dumping stations or other permitted outlets.

Only liquid run off from the shower and sink should be drained into your gray water tank. No other liquid is permitted to be drained into the gray tank. It is important to regularly clean your gray water tank as a build up of grease, dirt and soap scum can impact the function of the tank and cause odor. Please see refer to the OP15 Care and Maintenance section of this manual for proper cleaning steps and for cleaning and draining prior to storage. Do NOT use bleach to clean your gray water tank.





Black Water System & Toilet

The OP15 black water tank is located towards the front of the trailer on the lower edge of the driver's side. It can be identified by the black tank drain valve. The capacity of the tank is 10 gallons and the fill level can also be monitored using the gauge on the main control panel. We recommend emptying your black tank when it is at least 1/2 to 3/4 full and after every camping trip. Emptying your tank sooner may result in solid waste being left behind in your tank; a fuller tank allows more opportunity for breakdown of solid waste. All waste from the OP15 toilet is collected in the black tank so please take caution when emptying to avoid contact with waste which can carry harmful bacteria. The black tank must **ONLY** be disposed of in designated dump stations. At the rear of the trailer is a holding tube for the black tank drain hose. To empty your black tank:

- A. Remove the black tank hose from the storage tube by twisting the cap off D.
- B. Connect the drain hose to the drain valve by E. twisting on to receiver hooks
- C. Ensure the other end of the drain hose is directed
- into the appropriate dump point.
- To empty, pull the valve to open.
- Leave the valve open until you can no longer hear liquid waste draining then close the valve completely. Close the valve at this point

You can also use Formaldehyde-free black tank treatments such as the Camco TST Drop-ins to help breakdown waste and prevent odors. If you are on-site camping and connecting to a campground sewer we recommend keeping the tanks drain valve closed until you need to drain to assisting in purging the tank of solid waste. Please see the 'Bathroom' section of this manual for more information on using your toilet.

Warning: Do NOT leave waste in your tank during storage. Always remember to close the drain valve after draining the black tank and before removing the drain hose. Your drain hose should also be regularly cleaned and sanitized. Do NOT use bleach to clean your black water tank. Please see the care & maintenance section for further details on properly cleaning & sanitizing your black tank.

PROPANE GAS SYSTEM

Safe operating procedures for your propane gas system



The OP15 is fitted with a dual mount for two 20lb. **PROPANE** gas bottles and an automatic changeover dual regulator. Both bottles can be connected to the regulator at the same and the regulator will automatically switch between the gas bottles as required. The OP15 gas system will also work with only one propane tank installed. **Please ensure the gas bottles are turned off when the gas is not in use.**

To install a gas cylinder, place the gas bottle in the holder and use the provided clamp to hold the cylinder in place. Adjust the fit if necessary by turning the threaded triangle bolt. Ensure that you have the correct gas hose to connect the gas cylinder to the fixed gas regulator; your OP15 comes with a regulator-to-gas bottle pigtail hose which should be compatible with most US standard propane bottles. Once connected to the propane bottle, the gas tap/valve on the top of the gas bottle can now be opened.

To connect the gas system on the kitchen; stowed under the sink there is a gas hose fitted to the stove that has a quick connect on the other end. Thread the gas hose through the aperture under the kitchen and connect to the gas quick connect on the side of the OP15. Turn on the blue gas tap on the gas quick connect on the side of the OP15 by turning 90° so that it is parallel with the fixture.

To operate the gas stove; lift up the stainless steel lid, turn on one of the burners (push in, turn and hold to ignite). Keep pressing



the button until the gas has had time to fill up the system and the burner will ignite. You may need to hold the button in for up to 10 seconds before ignition to overcome the accidental ignition safety precaution in-built in the hob. **Do NOT lean across the burners to reach the stove controls.**

When the stove is not in use, please ensure the gas is turned off at the quick connect valve on the side of the OP15. If not using the Truma combi system, please also turn the valve on the gas bottles to the off/ closed position.

Please note that your Truma Combi System uses the propane system. Your propane tanks must be connected and in the open/ on position to supply the Truma Combi system to produce heat or hot water. Please refer to the section on the Truma Combi system for further information on how to operate.

You have an Propane (LP) / Carbon Monoxide (CO) detector installed in your OP15, direct wired to the battery. Please read the user manual supplied for the detector to fully understand correct usage. If the Propane or Carbon Dioxide warning alarm sounds, evacuate the trailer immediately and, if safe to do so, close off and fully disconnect the propane tanks. Do not touch any electrical switches.. Follow proper and safe steps to ventilate the trailer and await for the alarm to stop before returning to the trailer. If a propane leak is suspected fully disconnect the propane tanks and make an appointment to have your OP15 serviced with your dealership.

Ensure that the gas bottle valve is closed prior to packing up the OP15 for transit or storage, the quick connect valve on the side of the OP15 has been closed and that the gas hose has been disconnected from the side of the OPUS and carefully stowed inside the kitchen. Please make sure that the gas hose is fully inserted into the kitchen before sliding the kitchen into the storage compartment. Failure to do so can lead to the gas hose getting caught in the runners which can lead to damage.

Do not use any other gas systems than those provided with the OP15. Always turn off the shut off valve IMMEDIATELY after use.

PROPANE GAS SYSTEM cont.



WARNING! DO NOT PLACE PROPANE CYLINDERS INSIDE THE VEHICLE. PROPANE CYLINDERS ARE EQUIPPED WITH SAFETY DEVICES THAT RELIEVE EXCESSIVE PRESSURE BY DISCHARGING PROPANE TO THE ATMOSPHERE. PROPANE GAS IS HIGHLY FLAMMABLE. CAN LEAD TO A FIRE OR EXPLOSION AND RESULT IN DEATH OR SERIOUS INJURY.

DANGER! DO NOT USE GAS COOKING APPLIANCES FOR COMOFRT HEATING. CAN LEAD TO CARBON MONOXIIDE POISONING, WHICH CAN LEAD TO DEATH OR SERIOUS INJURY.

WARNING! GAS COOKING APPLIACNES NEED FRESH AIR FOR SAFE OPERATION: BEFORE OPERATING: OPEN VENTS OR WINDOWS SLIGHLY OR TURN ON EXHAUST FAN PRIOR TO USING COOKING APPLIANCES. GAS FLAMES CONSUME OXYGEN, WHICH SHOULD BE REPLACED TO ENSURE PROPER COMBUSTION, IMPROPER USE CAN RESULT IN DEATH OR SERIOUS INJURY.



WARNING! DO NOT FILL PROPANE CONTAINER(S) TO MORE THAN 80 PERCENT OF CAPACITY. A PROPERLY FILLED CONTAINER CONTAINS APPROXIMATELY 80 PERCENT OF ITS VOLUME AS LIQUID PROPANE. OVERFILLING PROPANE CONTAINER(S) CAN RESULT IN UNCONTROLLED PROPANE FLOW, WHICH COULD LEAD TO A FIRE OR EXPLOSION AND RESULT IN DEATH OR SERIOUS INJURY.



DANGER! IF YOU SMELL PROPANE:

- 1. EXTINGUISH ANY OPEN FLAMES AND ALL SMOKING MATERIALS.
- 2. SHUT OFF THE PROPANE SUPPLY AT THE CONTAINER VALVE(S) OR PROPANE SUPPLY CONNECITON.
- 3. DO NOT OTUCH ELECTRICAL SWITCHES.
- OPEN DOORS AND OTHER VENTILATING OPENINGS.
- LEAVE THE AREA UNTIL THE ODOR CLEARS. 6. HAVE PROPANE SYSTEM CHECKED AND LEAKAGE SOURCE CORRECTED BEFORE 5. **USING AGAIN.**

IGNITION OF FLAMMABLE VAPOURS COULD LEAD TO A FIRE OR EXPLOSION AND RESULT IN DEATH OR SERIOUS INJURY.



WARNING! WHEN USING THE OUTDOOR COOKING AREA, THE VEHICLE MUST BE LEVEL AND STABILIZED. DO NOT VIOLATE MANUFACTURERS' INSTRUCTIONS ON REQUIRED CLEARNACES FOR COOKING APPLIANCES DURING USE. DO NOT STORE COOKING APPLIANCES UNTIL COOL TO THE TOUCH, CAN LEAF TO A FIRE AND EXPLOSION AND RESULT IN DEATH OR SERIOUS INJURY.



DANGER! GAS FUMES INSIDE A CAMPER TRAILER COULD RESULT IN UNCONCIOUSNESS, BRAIN DAMAGE OR EVEN DEATH. FOLLOW SAFE OPERATING PROCEDURE WITH GAS AT ALL TIMES: ENSURE GOOD VENTILATION AT ALL TIMES.



DANGER! CHECK THE INSTRUCTIONS FOR CORRECT FITMENT AND SAFE USE WITH THE GAS CYLINDER MANUFACTURER/SUPPLIER.



DANGER! ALWAYS ENSURE THAT THE GAS CYLINDER RETAINING STRAPS ARE FITTED WHENEVER A GAS CYLINDER IS INSTALLED IN THE FRONT LOCKER COMPARTMENT, EVEN WHEN THE OPUS® IS STATIONARY.

IMPORTANT! PLEASE CONSULT THE OPUS TEAM BEFORE COMPLETING ANY REPAIRWORK ON THE GAS SYSTEM: THE PROPANE SYSTEM INSTALLED INCLUDES A 2-STAGE REGULATOR. THE REGULATOR MUST ALWAYS BE INSTALLED WITH THE VENT FACING DOWNWARDS.



THE PROPANE SYSTEM OF THE CAMPER IS DESIGNED FOR USE WITH THE SUPPLIED STOVE ONLY; DO NOT USE ANY OTHER GAS APPLIANCE WITH IT. THE PROPANE SYSTEM IS DESIGNED FOR USE WITH PROPANE ONLY. DO NOT USE OTHER FORMS OF GAS.

BLOCKAGES COULD RESULT IN EXCESSIVE PROPANE PRESSURE CAUSING FIRE OR EXPLOSION



PORTABLE FUEL-BURNING EQUIPMENT INCLUDING BUT NOT LIMITED TO WOOD & CHARCOAL GRILLS AND STOVES SHALL NOT BE USED INSIDE THE CAMPER DUE TO RISK OF FIRE OR ASPHYXIATION

THE REGULATOR IS LOCATED ON THE FRONT OF THE OP15. ENSURE THAT THE VENT FOR THE REGULATOR IS NOT OBSTRUCTED AS



TRUMA COMBI HOT WATER & HEAT SYSTEM



Truma Combi Hot Water & Heating System

The OP15 comes with the Truma combi eco hot water & heating system installed. This system is run off of your 12v power and propane gas supply. The system will provide hot water for your shower, bathroom and kitchen sink as well as forced hot air into the trailer.

We strongly recommend that you read the Truma Combi System manual that is provided with your trailer thoroughly before use for full instruction on how to operate and store/winterize

this appliance. Failure to follow the instructions in the Truma product user manual may result in serious injury or death. Damage caused by failure to follow the instructions will not be covered under warranty. In the event that you cannot find the manual, please visit www.truma.net/heating-systems/truma-combi-eco for a digital copy of the user manual.

The Truma system is installed in the exterior lockable compartment on the driver's side of the trailer. To turn the Truma Combi system on ensure your power and propane are both turned on. Use the Truma control panel located above the 12v TV on the side of the wardrobe to set the desired temperature. The Truma system can be used to provide either hot water only, forced hot air only or both concurrently. Please note however that using both the water heater and the forced hot air system at the same time will reduce the efficiency of both systems and cause the water to take longer to heat up.



Heater: Ducts for the forced hot air system can be found under the main OP15 control on the toe-kicker panel. There are three circular outlet vents to exit hot air and one rectangular vent for return air inlet.

Water Heater: The Truma has a 2.64gl holding tank capacity and uses water pumped directly from your potable water tank. The water will take approximately 20-25 minutes to reach temperature and will supply both sinks and the shower.

WARNING! Please keep all interior vents (air intake and exit) free of obstruction at all times. You must also keep the exhaust vent on the exterior front of the trailer free of obstruction too.

WARNING! Scalding injuries are caused by hot water! Water temperatures over 127 °F (52 °C) can cause severe burns or scalding and in extreme cases even death. Always test the water temperature carefully before use.

WARNING! FIRE OR EXPLOSION HAZARD - Failure to follow safety warnings exactly could result in serious injury, death or property damage. Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance. WHAT TO DO IF YOU SMELL GAS:

1.Evacuate all persons from the trailer,

2.Shut off the gas supply at the gas container or source,

3.Do not touch any electrical switch, or use any phone or radio in the trailer,

4. Contact the nearest gas supplier or certified service technician for repairs.

If you cannot reach a gas supplier or certified service technician, contact the nearest fire department.

Do not turn on the gas supply until gas leaks have been repaired.

SETTING UP YOUR OP15 AWNING

Girard 8' Manually Retractable Sun Awning

The OP15 Sun awning is a manually deployed 8' sun awning designed to provide shade over the kitchen area. You will find the supplied manual awning crank arm in the exterior slide out bin of your OP15. To set up your awning:

- 1. Ensure you have a minimum of 8' clearance from any nearby obstacles that may obstruct the awning before deploying it.
- 2. Insert the crank arm T-fitting vertically into the receiver located on the underside of the awning on the right side.
- Crank clockwise to extend the awning. Do NOT extend the awning to its maximum extension as this can damage the elbow joint. See image 3. below for suggested angle to deploy to.
- 4. To retract the awning, use the manual crank arm in the same receiver as above and crank counter clockwise until the awning is fully retracted and the crank mechanism prevents further turning.









IMPORTANT! Awning may only be used in very light wind and rain conditions. When periods of moderate rain and or wind are expected the awning must be closed. Please ensure the awning is retracted at the first sign of wind or rain conditions to prevent serious injury and damage. Damage caused by wind and rain is not covered under warranty. Never leave the awning open and unattended.

Please ensure your awning is fully retracted before moving your OP15 for any reason. Damage caused by failure to comply with this instruction is not covered under warranty. Damaged caused by collisions with objects in the area in which the awning will be deployed will not be covered under warranty. Do NOT over extend the awning. Ensure there is a good bend in the extension arm at all times.

Rooftop A/C





The OP15 comes fitted with a rooftop Dometic Penguin II 120v A/C unit. We strongly recommend that you read the instruction manual for this appliance in full before use for full instructions and maintenance information. Failure to follow the instructions may result in damage to the appliance which will not be covered under warranty.

You must be connected to a source of 120v electricity via either shore power or a generator to run the A/C unit as it will drain your batteries very quickly via the invertor.

Use the left hand dial to select the fan or cooling fan strength and use the right hand dial to select the temperature. Please keep all windows, doors and skylights closed for maximum efficiency when appliance is in use.

OP15 KITCHEN

Kitchen Features & Set Up

Your OP15 kitchen is located on the door-side of the trailer in a slide-out compartment. The compartment is secured with lockable push-button latches. The kitchen slide-out is held in place with spring-bolt locking pins. To open up the kitchen, pull the spring-bolts in and turn them so they catch and stay open then slide the kitchen out to its full extension. You can then access the kitchen-side quick connects for your gas and water connections (please see the **kitchen sink** and **Gas system** sections of this user manual

Stove Wind Protectors: The stove has two wind protectors that fold out to each side of the stove and secure in place with pins that slot into a hole on the kitchen surface. See the Propane Gas System for details on lighting the stove.

Slide-Out Surface: The kitchen has an additional slide out surface tucked under the stove. We recommend placing only lighter items such as oven mitts or cooking utensils on this slide out

Support legs: Folded underneath the slide out kitchen is a swing-down support leg. Push the button catch to release the leg. You can adjust the height of the leg as appropriate by loosening the wing nut pins to release the telescoping leg and then tightening them to hold it in place. To fold the leg away, retract the extendable leg fully and push the black end of the button catch to re-secure. There is also a secondary removable support leg pole which has a groove in the top that the underside of the kitchen fits into. This pole is also adjustable. We recommend using these support legs each time you set up the kitchen.

LED Light: Position the flexible light to the desired position. Plug the power cord for this light into the small 12v socket on the exterior of the OP15. Ensure that the ***Lights*** switch is turned on so that the socket is receiving power.

Dish/ Spice Rack: fold this up to vertical and set the rubber stand foot on the kitchen surface for stability.

Exterior Storage: Next to the slide-out kitchen is an additional storage compartment. You will find a selection of included accessories such as your hitch, stabilizer jack attachment, 30amp cable & dogbone adapter in this compartment for easy access to these items

Prep Deck: Built into the side of the OP15 you will find an additional fold-down prepdeck surface. This prep deck can hold up to 10lbs. When setting this surface up, push down on the hinge of the support arms to lock in place. Push upwards under the arms to release the hinge and fold the surface away. Please use both locks on the prep deck to lock securely in place during travel









OP15 KITCHEN cont.

WARNING! Ensure the spring-bolt locking pins are locked in place AND that the pushbutton locks on the door of the compartment are correctly closed and locked prior to travel. Failure to do so could result in serious injury and damage.

WARNING! Please make sure the spring-bolt locking pins are in the extended position at all times when the kitchen is set up so that the spring is not compressed. Failure to do so could result in serious injury. Take care to compress the locking pins again when closing the kitchen.

WARNING! Please ensure that all cords and hoses are disconnected and retracted prior to closing your kitchen to avoid damage.

IMPORTANT! Do not position the light over the stove. Always make sure that the power cord is removed from the outlet BEFORE sliding the kitchen away for storage to avoid damage to the light and the outlet.



<u>(i)</u>

Kitchen Sink

To Operate the kitchen faucet you must first connect the two supplied water hoses using the quick connects on both the slide out kitchen and the side of the OP15. Slide the kitchen out to its full extension. First connect the BOTTOM quick connect on the kitchen to the RIGHT hand quick connect on the side of the OP15. This is the cold water hookup. Next, connect the TOP quick connect on the kitchen to the LEFT quick connect on the OP15. This is the HOT water hookup. Please note that as the kitchen faucet is a hot/cold mixer faucet you must also turn on the Truma Combi system in order to receive water hot water. Please see the **Truma Combi System** section on how to set this up. If you would prefer to only use cold water, then you may connect only the cold water quick connect. The kitchen sink has a drain hose attached to the sink drain. This is designed to drain to a waste water container/ bucket and extends through the rear aperture of the kitchen.



WARNING: Do not pour hot oil down the sink drain.

About Your Fridge

We recommend reading the manufacturer's user manual that comes with your fridge in full to understand how this appliance works and to assist in troubleshooting should this be required. We have also compiled a few quick tips that are OPUS-specific:

- Your Fridge can be run on either 120v or 12v however we have designed the OP15 so that only 12v is supplied to the fridge compartment to enable the most energy efficient usage.
- The Fridge appliance is energy efficient and works well with minimum amperage draw. Please ensure that your fridge is set to 'low' or eco-mode to ensure you get the most efficient use and least impact on your 12v power consumption
- We recommend turning your fridge on and allowing it to come down to temperature 24 hrs before your trip and whilst connected to shore power as this is the time when your fridge will need to use the most energy
- You can leave the fridge turned on when you are travelling; simply ensure it is plugged in to the 12v socket in the storage compartment and that the fridge switch on the main control panel is turned on.
- Your fridge compartment is fitted with a fan-vent to help keep the temperature down in the compartment and so reduce the power consumption of the fridge. On hot days, you can also open the fridge compartment door but we recommend keeping the fridge inside the compartment when not in use to keep it shaded from the sun.



BATHROOM

Toilet

The OP15 toilet is a two-step flush toilet, connected to the potable water tank. In order to flush the toilet, first push the pedal (located on the right-hand side of the toilet base) down HALF WAY. This will fill the toilet bowl with water from your potable tank. Next, push the pedal down all the way to empty the toilet bowl. It is very important to complete the two steps including filling the toilet bowl with water, in order to ensure adequate water in the black tank allowing the break down of solid waste to facilitate the thorough emptying of the tank.

Do NOT throw trash or kitchen waste down the toilet as it will not break down in your black tank and can lead to clogging of your drain and interfere with the tank fill sensor.

- Only use single-ply RV toilet paper which breaks down faster
- Sparing use of toilet paper also means less solid waste to dissolve
- Always add water to the toilet bowl before flushing and flush regularly
- Compress the pedal smoothly and evenly to avoid damage
- Continually monitor your black tank level during your trip
- Keep your toilet lid closed when not in use to help minimize odors from your black tank



Shower

The OP15 shower draws water from your potable water tanks and drains to the gray water tank. In order to receive hot water to the shower, you must use the Truma Combi System. Please refer to the Truma Combi System section of this user manual.

IMPORTANT! Ensure the 12v fan on the ceiling of the shower is on when the shower is in use to prevent a build up of steam and moisture inside the shower room and camper. A build-up of steam can lead to light-headedness, loss of conscious and falls.

IMPORTANT! Water may be hot. Always test the heat of the shower before stepping into the shower flow.

IMPORTANT! The floor of the OP15 may become slippery when wet. Take care to keep water from the shower inside the shower room. Make sure the door, including the tent section is closed when

the shower is in use and any spilled water is dried immediately.

Do NOT plug or clog the shower drain. Take care to remove debris and hair from the drain in order to prevent flooding of the bathroom stall and unnecessary debris build up in the gray water tank. Be sure to clean the shower and controls regularly to prevent the build up of soap scum and limescale from impacting the effective function of the shower.

Sink

The sink on the OP15 is a mixer tap and draws water from your potable water system. To receive hot water to the sink, please follow the steps in the Truma Combi System section. Take care to test the heat of the water from the faucet as water may be hot.



TV & STEREO







Indoor/Outdoor 12v TV

The OP15 comes with a 12v TV mounted to the side of the wardrobe. To use the TV, ensure the 12volt power is turned on and that the TV is connected to the 12volt power socket AND the aerial socket located next to it on the side of the wardrobe. In the top drawer beneath the TV you will find the remote and manual for the TV. Please refer to the TV manual for further information on setting up your TV. Please note that the TV channels do not come pre-set so you may need to set the TV up to scan for local channels. This may apply for each journey you take in the OPUS, depending on channel coverage.

There is also an exterior mounting point for the TV located between the Kitchen and the prep-deck. To move the TV from the interior mount please first ensure all wires are unplugged from the outlets inside the trailer. To remove the TV from the bracket push the hooked clip at the bottom of the mount and slide the TV and the adjustable arm up to release from the tracks in the mount. To mount the TV to the exterior bracket slide the adjustable arm down into the tracks of the exterior TV mount until it clicks into place. Connect the two 12v power cables and the aerial cable to the outlets under the weatherproof protective cover.

WARNING! Always mount the TV to the interior mounting point during travel and use the installed straps to help to keep the TV secure.

WARNING! Do not use the TV on the exterior mount in wet weather even with the awning extended.

Stereo

The OP15 comes with an inbuilt stereo and both indoor and outdoor speakers. The stereo is mounted in the storage compartment above the main control panel and solar charge controller. It is compatible with Bluetooth connectivity as well as CD, Radio and direct connection via 3.5mil jack cable. There are two interior speakers and two exterior speakers. The toggle switch for either indoor OR outdoor speaker mode is mounted next to the solar charge controller panel below the stereo.







⊲opŰŝ 27

WINDOWS & DOOR

Window Screens

There are six windows solid-pane openable windows in the OP15 as well as zip-vent windows in the tent material of the roof. Each solid-pane window has two optional screens in addition to the standard clear window mode; a mesh insect screen & an opaque curtain screen.

The black clasp located on the center of the lower silver screen bar is used to lock the screens in place.

1.Slide the lower silver screen bar up to reveal the curtain screen.

2.As shown in the image, press the bottom of the clasp to lever the hook up

3. Hook the clasp over the lip of the top silver screen bar.

4.To release, press the clasp again and release the hook.

5. Slide the top silver screen bar down to reveal the mesh insect screen & lock in the same way.



The solid-pane windows are openable, hinged along the top edge. There are locking latches on each window^{*}. These latches also allow you to open the window to a 'vent mode' by latching on the secondary latch. **Remember to close fully for storage**.





Turn latches through 90° to clock/unlock. To open, push the window outwards from the bottom. Gas struts will hold the window in place at the point they are opened to.

To close the window, push it all the way open until you hear an audible 'click'. This will release the gas strut and allow you to close the window.

*Note some of the latches may have a release button in the center of the latch that needs to be pressed in order to turn the latch.



WINDOWS & DOOR

Entrance Door

The entrance door is fully lockable from outside with the key provided and from inside using the red lock latch. There is also a screen door for to protect against insects and provide ventilation. The screen door can also be unlocked using both an external key or the interior black latch on the door handle. There is also a slidable panel to allow you to close off the door handle access panel when using just the screen door.





Skylight

The skylight features a set of LED lights that can be controlled with the integral ON/OFF switch on the light itself.

The Skylight can be opened by turning the two black locking handles through 90° and then pulling the white handle down to release it from the holding catches then pushing upwards to open the window. To close the window, simply pull the white handle down and up into the holding catches.



The skylight also has both a black-out blind and a mesh insect screen. These screens simply slide out across the window (one is located at either side). Please note that if you slide the screen fully across to meet the screen on the other side, they will join via a magnet in the middle. To release, gently pull them apart.

Please ensure that the skylight is closed when rain is expected. Do not leave your OP15 unattended with the skylight open. Do not store your OPUS with the skylight open.

PACKING DOWN YOUR OP15

- 1. Ensure all windows and skylights are closed and the table is tucked up against the soar area and all cargo is securely stowed. Close all drawers and cupboards, and close and secure the bathroom door.
- 2. Stow and secure the TV in the interior mount, in travel mode.
- 3. Fold closed the main bed mattress. Stow the additional cushions.
- **4.7** Pull out the securing pins for the front and rear lifting mechanisms. Use the interior roof lift bars at the front and rear of the OP15 to pull the roof down. Slide the securing pins for the roof lifting mechanism into place to secure the roof in the travel position
- 5. Press the circular button on the left of the entry way to retract the electric step. Turn off the power and lights.
- 6. Disconnect from your 30ah connection and grey and black water drainage if on-site camping.
- 7. Close, latch and lock the entry door, prep deck and fridge/ heater storage compartments as required.
- 8. Ensure your kitchen sink is fully drained, close off your grey water carrier and stow it. Route your sink drainage hose back into the slide-out kitchen.
- 9. Turn off your propane at the tank. Disconnect your water and gas quick connects. Make sure the valves on the side of the OPUS are turned and retracted to the off position. Replace the dust covers as required. Stow the water hoses and retract the gas hose fully into the kitchen aperture.
- 10. Retract and stow the support leg, close down the stove lid, **disconnect the light from the 12v outlet**. Retract the spring bolts and slide your kitchen into the travel location. **Lock the securing pins into place.** Close the compartment door and lock.
- 11. At the rear of the trailer, un-hook the latch clamps on the rear panel and slide open the two locking pins. Use the handle to push the rear end wall panel down into travel mode.
- 12. Carefully raise the bed panel into the vertical position and slide the securing latches into place to the secure the panel for travel. **WARNING**! This panel is heavy especially considering the angle and reach required to hold it. We recommend two people complete this stage of the pack-down together. One person should hold the panel while the other person engages the catches. Failure to support the panel fully at this point could result in serious injury and damage to the trailer.
- 13. Using a helper to hold up the roof panel, close both side panels through 90 degrees then pull and turn the spring bolt handle to secure the side panels in place. WARNING! The roof panel will not stay in place once the side panels are closed. Please enlist a helper to prevent injury.
- 14. Fold the roof panel down and secure the push-button securing locks.
- 15. Fold the spare tire bracket up and secure the red-handled latches. Screw in the securing bolts
- 16. Latch down the four roof securing latches. Make sure they are tight when closed and do not move.
- 17. Retract and fold up your corner steadies.
- 18. Hitch up your trailer. Lower the tongue jack to assist in joining the vehicle side hitch to your trailer side hitch. Once connected, fold the jack up into travel mode. Make sure you lock the hitch in place.
- 19. Connect your breakaway cable, security chains and 7-pin cable. Complete your towing pre-journey checks.
- 20. Final check that all doors, panels and the roof are secure and locked and everything is disconnected from campsite hookups.
- 21. Always remember to disengage the e-brake before travel!

TROUBLESHOOTING

Water tanks

Issue: Water pump is running when all faucets & valves are closed

Troubleshoot: Leak in the system. Identify leaking fitting and attempt to tighten the fitting (usually hand-tight should be sufficient without the need for a wrench which could potentially over-tighten and damage the system. If still leaking, disconnect and check for debris or degrading within the fitting.

Issue: Water pump running but no water at faucets **Troubleshoot:** No water in tanks? Check for faulty sensor that could be misleading you to think that there is water in the tanks. Possibly the sensor needs cleaning or replacing.

Check the tank selector valve is directed at the correct tank (or both tanks are chosen). See page 18.

Propane System

Issue: Stove top won't stay ignited.

Troubleshoot: Press and hold the ignition/ dial for 10 seconds to overcome the safety thermocouple.

Consider the outside temperature; cold weather can cause the BTU of propane to drop. This can impact overall performance of the propane system. Keep your propane tanks full during cold weather and check other appliances that might also be using propane at the time.

OPUS CARE & MAINTENANCE

New Trailer Maintenance

Trailer breaks

Your electric drum breaks require a break-in period to achieve full and proper performance. This applies when you first receive your new OP15 then after new parts are installed as part of your maintenance schedule. Your OP15 brakes should be adjusted after the first 200 miles then every 3000 miles after that. We highly recommend that all break adjustments, maintenance and servicing is carried out by a qualified technician at your OPUS dealership.

CAUTION! You may need to adjust your brakes more frequently dependent on variations in cargo weights.

Suspension, Wheel and Hitch Bolts

After your first 50 miles then 500 miles after that please check the suspension bolts, wheel nuts and hitch bolts to ensure that they have maintained their tightness. This check should be completed with a torque wrench to 100 ft lbs. When tightening wheel nut lugs, please tighten bolts in a star-pattern order as indicated in the diagram to the right. After that, check your bolts every 2000 miles and always before an extended trp.

Potable Water Tank

Please be sure to flush and sanitize your potable water tank before first use.



6 LUG BOLT PATTERN

OPUS CARE & MAINTENANCE

Storage

- Pack down the trailer correctly and ensure nothing is out of place e.g. no canvas outside of the trailer, all windows and skylights are closed, all rubber gasket seals for storage compartments are intact and storage compartments are fully closed.
- Ensure your bathroom is fully dry before storing your OP15. If necessary, dry off the walls and tent material with a towel.
 Ensure the dust guards over the propage and water guide connects are gloganed periodically after guard the store and at least on
- Ensure the dust guards over the propane and water quick connects are cleaned periodically after every trip and at least once a year. Also make sure the dust guards are used when the hoses are not inserted.
- It is strongly advised that you purchase a storage cover for your OP15 if it is to be stored in an uncovered location. The storage cover is advised for an extended period of storage to keep your camper in pristine condition. Storage under a protective shelter is recommended.
- Clean off dirt and grime on the unit from travelling/terrain to keep your camper in good condition and maximize its longevity.
- Regular battery maintenance checks will prolong the life of your battery—see below section on maintaining your batteries during storage.
- Ensure the water tanks are emptied after use, and contain no liquids if being stored—see below section on water tank maintenance for further information.
- Park on a level surface, turn off all electrical switches and appliances, close all shades to prevent interior from UV damage. Be sure all windows, doors and vents are securely closed. Cover exterior appliance vents to prevent moisture and insects from entering during storage.
- Check the interior of the RV periodically to be sure leaks have not developed or that condensation has not formed, causing damage to interior components. Condensation can most readily be observed as moisture accumulation on windows and mirrors. To reduce the possibility of condensation, air out the RV occasionally during storage.
- Keep the roof free from snow and ice. Check it periodically and after a heavy snowfall.
- Store your OP15 covered or on level ground. Storage on unlevel ground can prevent proper drainage windows and seals leading to water ingress and potential mold or condensation issues.

External Care for your OP15

- Inspect the outside panels of your OPUS[®] including the roof for any damage, cracks or wear. Proper maintenance of seals is
 necessary to keep moisture from entering and causing severe damage such as rot, mold or mildew. If you find dry, cracked or
 weathered seals, reseal or replace as necessary. Check with your dealer for the type of caulking required for and correct
 methods of resealing or replacing.
- Inspect the sealant around the panels to verify that there is adequate bonding around the body panels. This is especially important after an impact/accident to the camper to ensure the integrity of the body's resistance to water ingress.
- Regularly check the seals of the camper, to ensure there has been no damage. Ensure your OP15 is closed properly to seal the trailer and stored on level ground to prevent water ingress. Failure to properly maintain your seals may be classed as neglect of maintenance and a decrease in coverage under your warranty.
- Keep the body and the roof of the camper clean, it is best to clean any mud and dirt off the camper immediately after every journey to maintain its clean finish.
- Inspect the condition of the frame, underbody, suspension and chassis regularly to keep it clean and address any damage that may lead to ruse. This is particularly important when driving during winter when road salts are in use. Always clean down your trailer fully if you have driven in snow, mud or wet conditions and is road salt use is suspected.
- Prolonged exposure to mud, dirt and salt may deteriorate the finish of the camper. Extended exposure to sunlight, air pollutants and excessive moisture can also negatively impact the finish of the camper. We recommend regular washing and protection during storage to maximize the lifespan of the finish.
- The body of the camper can be washed with soap and water using a soft sponge. Rinse the camper thoroughly after washing. Do not use a pressure washer as this can damage the finish. Avoid spraying water into vents and seals.
- A damp cloth may be preferred especially for small spots and dirt.
- Specialist products such as 'Waterless Wash and Shine' products may be used where/when adequate water is not readily available. Read and follow the instructions carefully and it is advisable to try any product to be used on the camper on a small inconspicuous spot to ensure/verify it is suitable before full use.
- Any form of damage or scratch to the paint work or finish of the camper on the body may be repaired or cleaned by using a suitable 'touch up' stick/paint. Contact OPUS[®] camper directly for further information.



Internal Care for your OP15

- All cabinetry in the camper should be kept clean for maximum longevity; stains can be wiped off with a small cloth. A damp cloth may be all that is required to remove most stains.
- Wipe off any spills and water residue on the units as soon as they occur to prevent damage to them or other features of the camper such as the electrics.
- AVOID using abrasives including sponge scourers to clean the units as these may cause scratches and issues with the finish of the units.
- AVOID placing hot objects/containers (cups/saucepans etc.) on the units directly; use a suitable mat/cover to prevent marking the surfaces of the units.
- The cushions in your OPUS[®] camper are durable and simply require proper care and use.
- Clean off stains and dirt on the cushions as soon as they occur; this can easily be done using a damp cloth. Avoid soaking the cushions or prolonged exposure to water and ensure they are thoroughly dry before packing the camper.
- Vacuum the cushions (and the trailer) regularly or as often as needed depending on level of use. Pay extra attention to the trims as these may contain some dirt or undesirable items.
- AVOID stepping on the cushions with shoes or placing dirty items on them.
- Condensation is caused by warm, moist air coming into contact with cold surfaces. Moisture can be introduced into your OP15 from the shower, warm bodies breathing out water vapor and perspiring in an enclosed, sealed space. If condensation is left unaddressed for long periods it can lead to mold or damp which can be damaging to your health. To avoid this, please ensure that your OP15 is well ventilated, particularly during the day after a nights sleep and after showering.
- Before storing your OP15, please use a towel to fully dry the interior shower cubicle and allow adequate ventilation and time for the tent material, seams and seals to dry to avoid condensation and mold.
- Be sure to check all water pipes, joints and fittings regularly for signs of leaks or seal failure. Water leaks can cause major damage inside your OP15. This also extends to all exterior joints and pipes.

Fire and Life Safety Devices

Your OP15 is fitted with a number of fire and life safety devices and comes with manuals and instructions for operating each device. These include:

- Propane Gas & Carbon Monoxide Alarm—Located in the footwell by the main bed, next to the 120v circuit panel
- Smoke Alarm—located on the roof next to the speaker and skylight
- Fire Extinguisher—located inside and to the right of the door.

Please read and familiarize yourselves with the proper usage and maintenance of these features before using your trailer as outlined in their respective manuals. It is possible that the alarms may sound when using products that give off vapors such as cleaning fluid, aerosols, adhesives etc. or if the sensor is covered by objects.

WARNING! Failure to regularly test and properly maintain these devices may lead to serious injury or death.

The following label has been placed on the interior of the main entry door and reads as follows: Do not utilize this RV unless fully set up because a secondary means of escape is not available. Can result in death or serious injury.

Your EMERGENCY EXITS are shown on the below floor plan



Potable Water Tanks

Please ensure you sanitize, flush and drain the water tanks before first use and after any period of storage.

To maintain the cleanliness of your potable water tanks please ensure all water is flushed from your potable water tanks after each trip or every two weeks when in use. Do NOT store water in the tanks for more than two weeks. To drain your potable water system:

- Turn off the water pump
- On bottom of both potable water tanks is a drain plug. Open this plug to allow remaining water to gravity drain. Ensure water is collected and disposed of in a responsible way.
- Ensure the drain plug is closed again before re-fill the tanks.
- Open your faucets/ shower / flush your toilet (you may need to step on the toilet pedal several times to flush the toilet system fully) and allow any residual water to drain. Close the faucets again.

We strongly recommend sanitizing your potable water tanks at least once every six months. If you suspect an issue with the quality of the water in your tanks or notice discoloration, odor or foul taste you should sanitize immediately. Always check your potable water source and use a fill hose listed for use with potable water.

To sanitize your potable water system:

- Flush all water from system as detailed above
- Use a potable water sanitizing product such as Camco TastePURE Spring Fresh Water System Cleaner
- Do NOT use bleach to sanitize the tanks as they are stainless steel and it will cause corrosion
- Follow the steps as directed on your potable water sanitizing product to fill, sanitize and purge as required.

Winterizing your potable water system

IMPORTANT! Before winterizing your OP15 you must have a water heater by-pass kit installed. Running RV winterizing fluid through your Truma Combi water heater can cause corrosion and Truma advise against this in their manual. If you will be winterizing your OP15 please discuss the installation of a by-pass kit for your water heater with your local RV service department.

- Set your water heater to by-pass mode.
- Drain the water from your potable water system following the above steps.
- Flush the water tanks with RV winterizing fluid; please follow the instructions on the label carefully to determine the correct dilution or amount of fluid to use.
- DANGER! Do NOT use automotive antifreeze to winterize your potable water system as they are highly toxic and ingestion may leave to serious injury or death
- Using the water pump, run this winterizing fluid through the entire water system including the faucets and shower as well. This will lubricate and protect your water pump and fittings during storage.
- DO NOT use the water pumps to run your tanks dry. Instead run the pumps to get some of this fluid through the system, then use the flush bolt underneath the water tank to drain the remainder of the fluid.
- After winter follow the steps above to sanitize your potable water system.

Please be advised that your Truma Combi system has a holding tank in it. Please ensure you carefully read the Truma Combi system manual for steps to drain the water heater tank of this appliance and prepare it properly for winterization. Always wait for the water heater tank to cool before draining. More information can also be found online at www.truma.net/about/news/ winterizing-your-truma-aquago-or-truma-combi.

Grey Water Tank

Open your grey tank drain valve and drain into an appropriate receptacle. Dispose of grey water responsibly at a dump station or drain point. Always check the rules for the state and campground that you are visiting to see what limitations may apply. Do not dump illegally. We recommend flushing your grey tank after dumping to help remove any unwanted build up.

For best maintenance of your grey water tank do not allow dirt, debris, hair or other solid material to drain into the grey tank. You may want to dump your gray tank after your black tank and use the grey water to help wash residue from the black tank sewer hose. See below section for winterizing your grey and black water tanks.

⊲opú≦° 34

To clean your grey water tank:

- Fill your grey tank at least half way full with clean water. Add an RV grey water tank cleaning solution/ tablet and follow the instructions for that product or use dish soap or laundry detergent 1/2–1 cup.
- Do NOT use bleach as it will corrode your tank, seals and gaskets. Any damage caused by using bleach is not covered under warranty.
- Take your OP15 for a spin to allow the grey water to slosh around and clean the inside of your tank and the tank sensors fully.
- You can then drain the grey water tank as above and we suggest rinsing it using a wand-style rinser afterwards.
- Following cleaning, use an RV grey water tank treatment to help dissolve grease and soap build up and prevent odors. We
 suggest using a natural, biodegradable enzyme based product that is formaldehyde-free such as Energen Grey Water Tank
 Treatment.

Black Water Tank

We recommend emptying your black tank when it is at least 1/2 to 3/4 full and after every camping trip. Emptying your tank sooner may result in solid waste being left behind in your tank; a fuller tank allows more opportunity for breakdown of solid waste. If you are on-site camping and connecting to a campground sewer we recommend keeping the tanks drain valve closed until you need to drain to assisting in purging the tank of solid waste. Follow the OPUS tips for best results when using your OP15 toilet. Please use caution when emptying to avoid contact with waste which can carry harmful bacteria. The black tank must **ONLY** be disposed of in designated dump stations. Do NOT dump illegally and follow all state and campground guidelines for safe and clean dumping. Use the black tank drain hose stowed at the rear of the trailer in the holding tube to drain your black tank

- A. Remove the black tank hose from the storage tube by twisting the cap off
- B. Connect the drain hose to the drain valve by twisting on to receiver hooks
- C. Ensure the other end of the drain hose is directed into the appropriate dump point.
- D. To empty, pull the valve to open.
- E. Leave the valve open until you can no longer hear liquid waste draining then close the valve completely. Close the valve at this point

WARNING: Do NOT leave waste in your tank during storage. Always remember to close the drain valve after draining the black tank and before removing the drain hose.

We recommend that you clean your black tank regularly and after draining. This will help to prevent build up of harmful bacteria, solids and odors as well as helping to keep your tank sensors clean and clear of obstruction. **Do NOT use bleach to clean your black water tank as it can cause corrosion.**

To clean your black tank:

- Drain and dump any waste by following the steps above
- Take measures to remove any build up from the tank walls. We recommend wand-style rinsers such as the Camco Swivel Stik that can be used with the toilet drain open to access the black tank.
- Use a treatment product to clean your black tank. We recommend using a biodegradable, eco-friendly product that is enzymebased. Please take care to ensure your treatment is formaldehyde-free—many dumping regulations now require this as standard. Follow the instructions on your chosen cleaning treatment to ensure the appropriate dilution as required. If you need to add water for your chosen product, you can do this by filling and flushing the toilet bowl several times.
- If your sensors are not reading accurately and flushing the tank does not resolve the problem, tank sensor cleaning products are available to help remove buildup.
- Your drain hose should also be regularly cleaned and sanitized.

Winterizing your grey and black water systems:

- Fully drain an clean the grey and black water tank following the above steps. Close your drain valves after draining.
- Flush RV winterizing fluid down your bathroom sink, shower drain and toilet (without flushing; ensure the drain valve is closed).
- Winterizing fluid can remain in the tanks while in storage.
- **IMPORTANT**! Monitor water temperatures closely in severe cold in case you must take the steps to drain and winterize your water systems whilst camping

Greasing and Servicing

The electrical and propane systems will need to be checked over by an RV service technician. The lug nut torque requirements are 100ft lbs.

WARNING! Never use the levelling jacks to lift the trailer completely from the ground for any reason including servicing, repair work or tire changes. To do so would cause the trailer to become unstable and unsafe. Always useful proper lifting equipment or have the work completed at an approved service location.

The servicing schedule may be affected by your usage amount and operating conditions. Discuss your intended use and servicing timetable with your dealership to find the optimum schedule for your OP15. It is always better to attend to or catch small problems early or before they occur rather than allowing problems to become larger or impact other systems or areas of your trailer. Failure to service your trailer in a timely manner may mean that issues may full outside of or void your warranty due to failure to complete proper maintenance (neglect).

The servicing requirements are:

- Check the wheel bearings every year ensure these are checked by a qualified service technician.
- Check the lug nuts every 2000 miles this includes the spare tires nuts.
- Check the tire pressure every 2000 miles the tire sticker on the interior of the door will supply the appropriate pressure.
- Have the dual coil suspension serviced every year; a dealership will complete the following services:
 - Check and ensure the Zerk fittings on the suspension are in good condition and that these are removed and the suspension well oiled.
 - Utilize a grease gun kit and some Moly-Grease .
 - Check that the coil suspension is well greased (Moly-Grease suitable for suspension coils will also be acceptable here).
 - Grease the hitch with some compound similar to Reese Heavy Duty Hitch Lubricant .
 - Winterize the water tanks (see water system care & maintenance section).
- Look for signs of chipped paint around the body work. We can supply a cover paint kit to dress this.

Battery Care and Maintenance

- Battery type: AGM.
- Best way to charge: Apply saturated charge to prevent sulfation; can remain on charge with correct float voltage.
- Charge methods: Constant voltage to 2.40-2.45V/cell, float at 2.25-2.30V/cell. Battery should stay cool -- no fast charge possible.
- Charge time: 14-16 hours.
- Discharge: Can endure high peak currents. Avoid full discharges. Charge after each use.
- Storage: Keep cells at >2.05V. Apply topping charge every 6 months to prevent sulfation.
- Disposal: Toxic. Do not dispose. Electrolyte corrosive. Profitable to recycle.
- How to prolong battery life:
 - Limit deep cycling.
 - Do not deep-cycle starter battery.
 - Apply fully saturation charge.
 - Avoid heat.
- Transport : Flooded: Class 8 restrictions, provide "corrosive" label. Non-spillable: Class 8 exempt.

Winterizing your batteries/ long periods of storage

We have spec'd the Opus so you have the ability to leave your Opus plugged in without the need to remove the 30ah cable. We have done this because the CO Alarm is hard wired to your batteries and therefore your batteries will supply a constant current to this appliance. In order to prevent your batteries from being completely depleted over long periods of storage

- 1. Completely charge the battery before storage
- 2. Store the battery in a cool, dry location. Heat is a battery killer. Do not forget to completely remove all loads from the battery (turn off your battery disconnect or remove the connection to your battery post).
- 3. Monitor the specific gravity or voltage. Once below 70% charge, give it a boost charge.
- 4. Completely recharge the battery before putting back in service. 5. Equalize the battery before putting back in service.

Following the above would mean that you need to disconnect the batteries entirely from your system, this would result in the Air Compressor not operating after winter storage; you would therefore need to manually inflate the tent for your first use. Our advice for simplicity of use would be to leave the camper plugged in, NOCO advertises that this is acceptable practice. If you want to be defensive over the longevity of your batteries then please remove them entirely from your Opus and store safely, then

Return to the Road

Ensure that your camper and accessories are fit for the road and you adhere to all local laws.

- Check the wheels and tires and ensure they are in good condition with the bolts correctly torqued.
- Check tire pressures once a month and before any extended trips
- Check to ensure all bolts are tightened on the under carriage.

inflate the tent using the manual pump supplied for first use.

- Check the lights and fittings and ensure they are functioning correctly.
- Check the brakes are in good working order
- The chassis/running gear and the gas installation of your OP15 camper should be checked on an annual basis by a qualified service center.
- Purge your water tanks, sink and toilet of winterizing fluid
- Change your water heater from by-pass mode to normal mode
- Sanitize your potable water tank and add a treatment to the grey and black tanks as required.

Customer's Responsibilities

In order to ensure you get the most out of your OP15 and that warranty claims may be processed in a swift and timely manner, we ask that our customers adhere to the following guidelines:

- Regular and proper maintenance of your OP15, including but not limited to the steps outlined in this user manual. If you have
 maintenance or service questions not covered by this manual OR you notice something out of the ordinary with your camper
 please contact your dealership for more information This includes scheduled maintenance of your OP15 and addressing any
 issues as they arise and without delay
- 2. Get to know your OP15 well. By learning about your camper and its components you will get an enhanced user experience and avoid issues arising from mis-handling as well as become more likely to spot if something requires additional servicing
- 3. It is the responsibility of the OP15 owner to ensure all warranty work is completed by an approved OPUS dealership. Failure to do so may result in incomplete or refusal of warranty claim repair cost reimbursement.
- 4. Any modifications without written consent from OPUS Camper could result in loss of warranty coverage. Contact us or your dealer before completing any work.

OPUS WARRANTY - PAGE ONE

Introduction

The following information relates to warranties offered by OPUS[®]. Please read all the information carefully, and should you have any questions relating to any aspect of this section, please contact OPUS[®]. By purchasing an item from OPUS[®], you hereby agree to all terms and conditions of warranty as set out herein

Validity of Claims

- Warranties are only valid to the original purchaser of the item in question and are valid from the original date of purchase only.
- Warranties apply only to items sold as "new" and do not extend to any items sold via auction, or deemed to be "factory seconds", "exdemonstration "or "damaged" unless specifically stated otherwise by OPUS[®] in writing. (Please see further on this page for more information).
- Warranties are not transferable under any circumstances. Similarly, if an item is sold to a third party by the original purchaser, then all warranties become null and void, and the original purchaser shall make no claims or be eligible for any claims on behalf of the new owner.
- Warranties do not apply to products purchased from OPUS[®] and then used in hire schemes; as rentals; or for commercial or business purposes
- OPUS[®] does not cover damage due to unauthorized modifications, misuse, abuse, incorrect assembly, improper and irregular maintenance, or accident or collision.
- Any work performed under an authorized warranty claim approved by OPUS[®] must be performed by OPUS[®], or an authorized representative of OPUS[®] and only with the express written permission of OPUS[®]
- Any affiliates, representatives, associates, agents, suppliers, resellers or similar of OPUS[®] shall have no authority to authorize or deny warranty claims on behalf of OPUS[®]
- OPUS[®] shall not be liable, (in part or whole) for any warranties, either express or implied, made by agents or resellers on behalf of OPUS[®] without the knowledge or express written permission of OPUS[®]. Such unauthorized claims shall be the responsibility of the agent or reseller only.

Camper Trailers

Unless stated otherwise, trailers only are covered by a 24-month limited manufacturer's warranty from the original date of purchase. Our goods come with guarantees that cannot be excluded under Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. OPUS® includes equipment and fittings, such as stoves, refrigerators, and sinks, which are separately warranted by their manufacturer and not covered by Opus®^{*} Warranty. If necessary, OPUS® will help an owner make a warranty claim to these manufacturers. In addition to: OPUS® warranty, the consumer may also be covered by other rights and remedies of Consumer Law per state and/or federal regulations in relation to the goods and or services to which this warranty relates. Under no circumstances should OPUS® campers be exposed to water crossings at, or above, body floor level. The following items are not covered under Opus®' warranty: Impact or stone damage to body, chassis or running gear; soiling of fabrics and internal fitments from dust and other airborne substances; water damage due to water crossings; movement or damage caused by dislodgement of appliances and fittings resulting from hard impact or heavy landings or severely rutted roads or tracks; general damage arising from misuse; rust; wheels and tires; paint; travel covers and straps; general consumables (e.g. bearings, light bulbs etc); damage due to condensation; normal wear and tear; exposure to elements; wear and tear when the RV has been used for permanent living purposes. This trailer is designed solely for its intended purpose of recreational camping and personal use. OPUS® does not warranty trailers used for commercial, rental, or business purposes, or any recreational vehicle not registered and regularly used in Contiguous 48 states of the United States.

No action to enforce express or implied warranties shall be commenced without prior written notice to OPUS® at the address listed below of the alleged defect or nonconformity or the authorized repair facility's failed repair attempt and OPUS®, AT ITS DIRECT OPTION, SHALL HAVE A FINAL OPPORTUNITY TO REMEDY.

...CONTINUED ON NEXT PAGE



OPUS WARRANTY - PAGE TWO

Purchaser's Obligations

The Purchaser shall deliver this camping trailer for warranty service within a reasonable time after discovery of the defect and in no event after expiration of the Warranty Period, which Warranty Period is twenty four (24) months. All expenses incurred by the Purchaser in obtaining warranty service shall be borne by Purchaser. Warranty service shall, whenever possible, be scheduled with the selling dealer by an appointment in order to avoid possible delays. Purchaser can, if necessary, obtain a list of persons authorized to perform warranty service by contacting OPUS® at the below address. No action to enforce express or implied warranties shall be commenced without prior written notice to OPUS® at the address listed below of the alleged defect or nonconformity or the authorized repair facility's failed repair attempt and OPUS® , AT ITS DIRECT OPTION, SHALL HAVE A FINAL OPPORTUNITY TO REMEDY.

Disclaimer of consequential and incidental damages

The original consumer purchaser of this camping trailer and any person to whom this unit is transferred, and any person who is an intended or unintended user or beneficiary of this unit, shall not be entitled to recover from OPUS® any consequential or incidental damages.

Events discharging OPUS from obligation under this warranty

Misuse or neglect, including failure to provide reasonable and necessary maintenance, unauthorized alteration, accident, and improper loading, commercial use or leasing of the recreational vehicle, shall discharge OPUS® from any obligation under this Warranty.

Parts and design changes

OPUS[®] reserves the right to change the parts and design of its recreational vehicle from time to time without notice and with no obligation to maintain spare parts or make corresponding changes in its products previously manufactured.

Factory Seconds, Ex-Demonstration and Damaged Goods

From time to time, OPUS[®] may offer for sale items deemed to be "factory seconds", "ex-demonstration", or "damaged". Any items sold as "factory seconds", "ex-demonstration" or "damaged" items are sold on an "as is" basis. There are no warranties, refunds, credits, exchanges or similar associated with such items. In the sale of such items, OPUS[®] will attempt to provide all relevant information regarding the item, including faults, defects, or similar, however, there may be instances where minor defects or imperfections have been overlooked. This is PURELY UNINTENTIONAL and in no way alters the nature of the sale. Due to the nature of such items, i.e being "ex-demonstration", "factory seconds" or "damaged", it is reasonable to expect that some imperfections or flaws may exist even where it is not initially apparent. By purchasing such an item, you agree to this statement in full and accept that there are no warranties

Owner Assistance

Your continued confidence and goodwill are important to us at OPUS[®] as is maintaining a good relationship with our dealers. OPUS[®] recognizes that there may be occasions when a warranty or service problem is not handled to your satisfaction. We encourage you to attempt to rectify the situation by discussing the situation with your local dealership management; if after this your problem is not resolved to your satisfaction we welcome you to contact OPUS[®] at the below address. We will provide our recommendations for an agreeable solution to the local dealership.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

Lodging a Claim

All warranty claims can be lodged by contacting your dealership.

Contact

If you have any further questions relating to warranties, or are unsure about any aspect of this section, then please contact us.

Phone: 925 215 7315 Email: info@opuscamper.us Address: 1850 Loveridge Rd, Puttsburg, CA 94565

Internal Features











Bamboo interior finish with wardrobe and drawer storage compartments.



Navy blue leatherette cushions and moveable bamboo table



Personal, adjustable LED lights for each bed



Two interior speakers

Smoke & LP.CO alarms Fire extinguisher





NOCO Genius battery charger and 12v to 120v power inverter

External Features





Front Rock Guard

Two jerrican holders



Lighted Handle



Exterior LED Lights



OPUS Heavy Duty Mudflaps



Two Exterior Speakers



12v Dual Compartment Refrigerator/ Freezer



Exterior Slide out storage



OPUS Accessories













Top Row:

- 1. 30a Power Cable
- 2. Dogbone adapter for home plug-in
- 3. Wheel Chocks

From Left:

- 1. Kitchen Slide-out chopping board support leg
- 2. Drill-bit adapter for corner stabilizers
- 3. Adjustable exterior LED light
- 4. Manual crank handle



For further information please contact the OPUS® Team

R

F-RO

925.215.7315

info@opuscamper.us

www.opuscamper.us

Find us on facebook & Instagram!

Photographs and diagrams are for illustration purposes only. Actual product may vary and any specifications are subject to change without prior notice.

All information correct at time of print. Purple Line LLC 2020